

Certificated Aerodrome 3NM S of Taupo

TAUPO

NZAP

OPERATIONAL DATA (1)**RWY**

RWY	SFC	Strength	Gp	Slope	ASDA	Take-off distance			LDG DIST
						1:20	1:30	1:62.5	
17 35	B	PCN 20 F/C/Y/T	8	0.24D 0.24U	1386			1447	1386
10 10	Gr	ESWL 2270	3 5	1.15U		700			700
28 28	Gr	ESWL 2270	5 3	1.15D		700			700

MINIMA

IFR Take-off		
RWY	Day	Night
17/35	500-1500	500-2000

LIGHTING

I Runway: 17/35 CGL, PAPI 3.0°/TCH 46 LIL RWY
Turning BCN FLG W LIH, 1.2NM S RWY 35 THR

D

Aerodrome: WDI

Taxiway: Edge HLDG POSN A Apron: Edge and floodlighting

Remote control of lighting available on request from Christchurch Control (Bay Sector) 123.6 MHz, advising runway to be used. Outside Bay Sector hours of service contact Christchurch Information 123.6 MHz or by phone 0800 626 756 (landline users only) or 0900 62 675 (cellphone users). Brilliance adjustments may take up to 1 minute to action.

Advise Christchurch when requirement complete.

Caution: Lights will not operate or settings will not be able to be changed if communication line failure occurs.

Standby power available.

FACILITIES

Fuel: Avgas 100, Swipecard.
Z Energy Jet A1, Access via Z card
Z Energy Avgas 100, Access via Z card, Outside Aero Club
Jet A1 – site specific access required
Air BP Avgas 100, Swipecard
Air BP Jet A1 access via Air BP Card

Passenger: Limited repairs

Vehicle access airside restricted except by prior arrangement.

AFRU provides confirmation of radio frequency and equipment serviceability.

SUPPLEMENTARY

Operator: Taupo Airport Authority, RD2, Taupo
Tel (07) 378 7771, Fax (07) 378 7776
Email: admin@taupoairport.co.nz

For further information visit website www.taupoairport.co.nz

Fees:

- aerodrome landing charges are payable for all landings at Taupo Aerodrome
- a schedule of charges is available on application to the Aerodrome Operator
- aerodrome landing charges will be invoiced to the registered aircraft owner as per the Civil Aviation Register of Aircraft unless prior arrangement has been made with the Taupo Airport Authority
- landing charges may be paid in cash at the time of landing to the airport management office or to the honesty box located adjacent to the aero club

Available for general use without the permission of the operator.